PremiumCARE

1,000+ Covered Component Parts (Partial List)

- Actuator - Front Radius Arm
- Actuator - Front Spring
- Actuator - Rear Axle
- Actuator - Rear Spring
- Actuator - Solenoid - Rear Spring
- Actuator - A/C Cond
- Actuator - ABS Tube
- Actuator - Front Spring
- Actuator - Front Suspension
- Actuator - Lift Assembly - Steering
- Actuator - Steering Gear
- Actuator - Steering Gear Assembly
- Actuator - Steering Gear Assembly
- Actuator Assembly - Steering Gear
- Actuator Assembly - Steering Gear
- Actuator Assembly - Steering Gear

Premium Maintenance Plan

Our most comprehensive maintenance plan covers:

- Engine Oil and Filter Changes
- Tire Rotations/Inspections
- Tire Rotations
- Replacement of Brake Pads and Linings When Worn
- Shock Absorber Replacements
- Belt Drive
- Clutch Discs
- Engine Belts
- Wiper Blades, Clamps and O-ring Seals
- Wiper Motors
- Diesel Exhaust Fluid Fill at the Time Scheduled Maintenance Is Performed at Dealership (If Necessary)

Essential Maintenance Plans

Plan ahead now and protect yourself against rising maintenance costs with this affordable array of standard service items for your vehicle.

- *Limited Maintenance covers labor/oil/filter, tire rotation, diesel exhaust fluid refill at service visit and wiper blade replacement.*
- *Basic Maintenance covers labor/oil/filter, tire rotation, multi point inspection.*
- *Engine Maintenance covers labor/oil/filter only.*

PowertrainCARE 29 Covered Component Parts

- A/C Clutch
- A/C Clutch Bearings
- A/C Compressor
- A/C Compressor Clutch Switch
- A/C Compressor Head
- A/C Compressor Seals
- A/C Compressor
- A/C Field Coil
- Belt Drive
- Hubs, Automatic Front-Locking (Four-Wheel Drive)
- Locking Rings (Four-Wheel Drive)
- Manifold (Exhaust and Belts)
- Manifold Intake and Belts
- Oil Cooler
- Oil Pump
- Seals and Gaskets (Engine)
- Seals and Gaskets (Front and Rear Wheel Drive Axle)
- Seals and Gaskets (Transmission)
- Thermostat
- Thermostat Housing
- Timing Chain (Gears or Belt)
- Timing Chain Cover
- Torque Converter
- Transfer Case Shielding (All Internal Parts)
- Transmission Case (including All Internal Parts)
- Turbocharger/Supercharger Unit (Factory-Installed)
- Universal and Constant Velocity Joints (Front- and Rear-Wheel Drive Axle)
- Valve Covers
- Water Pump

BaseCARE 84 Covered Component Parts

- A/C Clutch
- A/C Clutch Bearings
- A/C Compressor
- A/C Compressor Clutch Switch
- A/C Compressor Head
- A/C Compressor Seals
- A/C Compressor
- A/C Field Coil
- Belt Drive
- Hubs, Automatic Front-Locking (Four-Wheel Drive)
- Locking Rings (Four-Wheel Drive)
- Manifold (Exhaust and Belts)
- Manifold Intake and Belts
- Master Cylinder
- Metal Fuel Lines
- Oil Cooler
- Oil Pump
- Parking Brake Linkage & Cables
- Power Steering Pump
- Pulley (Key (Power Steering Pump)
- Seals and Gaskets
- Seals and Gaskets (Engine, Front and Rear Drive Axles, Steering & Transmission)
- Self-Adjusters (Brakes)
- Shock Absorbers
- Speedometer/Odometer (Electrical & Mechanical)
- Spindle and Spindle Supports (Front & Rear Suspension)
- Starter Motor
- Stabilizer Bar (Front & Rear Suspension)
- Steering Gear
- Steering Gear Housing
- Steering Gear Housing, Manual and Power (Including All Internal Parts)
- Switches (Manually-Operated Dash)
- Thermostat (Engine)
- Thermostat Housing (Engine)
- Tie Rods (Front Suspension)
- Timing Chain (Gears or Belt)
- Timing Chain Cover
- Torque Converter
- Transmission Case
- Turbocharger/Supercharger Unit (Factory-Installed)
- Universal and Constant Velocity Joints (Front and Rear-Wheel Drive Axles)
- Valve Covers
- Voltage Regulators
- Water Pump
- Wheel Cylinders
- Wiper Motors
- Wiring Harnesses (Including Spark Plug Wires)

ExtraCARE 113 Covered Component Parts

- A/C Accumulator
- A/C Clutch
- A/C Clutch Bearings
- A/C Compressor
- A/C Compressor Clutch Switch
- A/C Compressor Head
- A/C Compressor Seals
- A/C Condenser
- Adaptive Cruise Control
- Air Conditioner Components (Activated Carbon)
- Anti-Lock Brake Module & Sensor
- Automatic Temperature Control
- Axle Shafts (Front- and Rear-Wheel Drive Axles)
- Backing Plates (Brakes)
- Ball Joints (Upper & Lower)
- Brake Booster (Power)
- Calipers (Brakes)
- Camshaft (Front-Wheel)
- Combination Valve (Brakes)
- Control Arms (Upper & Lower)
- Control Arm Shafts & Bushings (Front & Rear Suspension)
- Control Module (Engine)
- Cradle & Metal Liners (Steering)
- Cylinder Block
- Cylinder Heads
- Diesel Injection Pump
- Diesel Injector Pump and Lines, Diesel Injection Pump
- Diesel Lift Pump
- Differential Housing
- Distributor Cap & Rotor
- Drive Axle Housing & Front Axle Housing for 4x2 (Including All Internal Parts)
- Electronic Ignition Module
- Engine Mounts
- Evaporator (A/C)
- Fuel Injectors
- Front Drive Housing & Rear Axle Housing for AWD (Including All Internal Parts)
- Flywheel
- Flywheel Ring Gear
- Fuel Pump
- Fuel Tank and Metal Lines
- Gas & Diesel Fuel Injectors and Metal Fuel Lines
- Harmonic Balancer & Belt
- Hydraulic Unit (Electrical Only - No Brake, Damper or Brakelight)
- Hydro-Boost
- Ignition Module
- Ignition Switch
- Instrument Cluster, Electronic (Excluding Dash Pad, Dash, Audio and Visual Equipment)
- Keyless Entry System (Excluding Key Fob Batteries)
- Kingpins & Bushings (Front Suspension)
- Lines & Fittings (Brakes)
- Linkages & Bushings (Steering Gear)
- Linkages & Couplings (Steering)
- Locking Rings (Four-Wheel Drive)
- Mouthpiece Block (Front)
- Master Cylinder
- Metal Liners and Bolts)
- Manifold Intake and Bolts
- Metal Lines & Fittings (Brakes)
- Oil Pan
- Oil Pump
- Parking Brake Linkage & Cables
- Power Antenna
- Power Door Locks & Retainer Clips
- Power Seat Components
- Power Seat Motors
- Power Steering Pump/Electric
- Power Steering Actuator
- Power Window Motors/Regulators
- Pulley (Key)
- Pulley Assembly, Power Steering Pump (Steering)
- Radiator & Radiator Fan
- Radiator Fan Clutch or Motor
- Rear Axle Housing
- Rear Hub Bearings
- Seals & Gaskets (Engine, Transmission, Front- and Rear-Wheel Drive Axles & Steering)
- Sector/Cam* Keyless Entry Remote Control Fob
- Shaft (Brake Pedal)
- Speed Control
- Speedometer/Odometer (Electrical and Mechanical)
- Spindle & Spindle Supports
- Springs (Brakes)
- Stabilizer Bar
- Starter Motor
- Starter Motor Solenoid
- Steering Gear Housing, Manual & Power (Including All Internal Parts)
- Steering Knuckle/Housing (Front-Wheel Drive)
- Steering Linkage
- Steering Wheel
- Suspension Clutch Gear
- Switches (Manually-Operated Dash)
- Thermostat (Engine)
- Thermostat Housing (Engine)
- Tie Rods (Front Suspension)
- Timing Chain (Gears or Belt)
- Timing Chain Cover
- Torque Converter
- Transmission Case
- Turbocharger/Supercharger Unit (Factory-Installed)
- Universal and Constant Velocity Joints (Front and Rear-Wheel Drive Axles)
- Valve Covers
- Voltage Regulators
- Water Pump
- Wheel Cylinders
- Wiper Motors
- Wiring Harnesses (Including Spark Plug Wires)

PremiumCARE 1,000+ Covered Component Parts (Partial List)

- A/C Accumulator
- A/C Clutch
- A/C Clutch Bearings
- A/C Compressor
- A/C Compressor Clutch Switch
- A/C Compressor Head
- A/C Compressor Seals
- A/C Compressor
- A/C Control Head
- A/C Field Coil
- Air Conditioner Components (Activated Carbon)
- Anti-Lock Brake Module & Sensor
- Automatic Temperature Control
- Axle Shafts (Front- and Rear-Wheel Drive Axles)
- Backing Plates (Brakes)
- Ball Joints (Upper & Lower)
- Brake Booster (Power)
- Calipers (Brakes)
- Camshaft (Front-Wheel)
- Combination Valve (Brakes)
- Control Arms (Upper & Lower)
- Control Arm Shafts & Bushings (Front & Rear Suspension)
- Control Module (Engine)
- Cradle & Metal Liners (Steering)
- Cylinder Block
- Cylinder Heads
- Diesel Injection Pump
- Diesel Injector Pump and Lines, Diesel Injection Pump
- Diesel Lift Pump
- Differential Housing
- Distributor Cap & Rotor
- Drive Axle Housing & Front Axle Housing for 4x2 (Including All Internal Parts)
- Electronic Ignition Module
- Engine Mounts
- Evaporator (A/C)
- Fuel Injectors
- Front Drive Housing & Rear Axle Housing for AWD (Including All Internal Parts)
- Flywheel
- Flywheel Ring Gear
- Fuel Pump
- Fuel Tank and Metal Lines
- Gas & Diesel Fuel Injectors and Metal Fuel Lines
- Harmonic Balancer & Belt
- Hydraulic Unit (Electrical Only - No Brake, Damper or Brakelight)
- Hydro-Boost
- Ignition Module
- Ignition Switch
- Instrument Cluster, Electronic (Excluding Dash Pad, Dash, Audio and Visual Equipment)
- Keyless Entry System (Excluding Key Fob Batteries)
- Kingpins & Bushings (Front Suspension)
- Lines & Fittings (Brakes)
- Linkages & Bushings (Steering Gear)
- Linkages & Couplings (Steering)
- Locking Rings (Four-Wheel Drive)
- Mouthpiece Block (Front)
- Master Cylinder
- Metal Liners and Bolts)
- Manifold Intake and Bolts
- Metal Lines & Fittings (Brakes)
- Oil Pan
- Oil Pump
- Parking Brake Linkage & Cables
- Power Antenna
- Power Door Locks & Retainer Clips
- Power Seat Components
- Power Seat Motors
- Power Steering Pump/Electric
- Power Steering Actuator
- Power Window Motors/Regulators
- Pulley (Key)
- Pulley Assembly, Power Steering Pump (Steering)
- Radiator & Radiator Fan
- Radiator Fan Clutch or Motor
- Rear Axle Housing
- Rear Hub Bearings
- Seals & Gaskets (Engine, Transmission, Front- and Rear-Wheel Drive Axles & Steering)
- Ball Joint Assembly
- Ball Joint Assembly (Ballast, HI-Mount Stop Lamp
- Bench - Front
- Bench - Rear
- Bench - Transmission Reverse Idler Gear Assembly - Transmission Intermediate
- Barometric and Map Sensor
- Battery - Auxiliary Power
- Bearing - Coupling Shaft
- Bearing - Differential Adjuster
- Bearing - Front Axle
- Bearing - Packing Brake
- Bearing - Rear Axle Shaft
- Bearing - Warm Gear
- Bearing - Assembly - A/C Comp Clutch
- Bearing Assembly - Air Comp
- Bearing Assembly - Suspension Compressor
- Bearing Assembly - Band Shift Bearing Assembly
- Bearing Assembly - Spindle
- Bearing, Cup Front Wheel
- Bearing Front Wheel
- Bearing, Seal Front Suspension
- Bearing, Cup Intermedia Lubricated
- Belt Assembly, Center-Pass Idler/Spreader
- Blend Spool Sensor Bracket
- Blend Spool Sensor Module
- Electrical Wiring
- Block Fuel Tube Support
- Block Fuel Tube Support
- Blower Motor Assembly
- Body Assembly
- Brake Booster
- Bolt - Door Shift Housing
- Bolt - Front Axle Steer Case
- Boost Pressure Sensor
- Booster Assembly - Brake
- Power Brake
- Boot - Brake Cylinder
- Brake Drum
- Brad - Drive Shaft Joint
- Brad - Downshift Control
- Brad - Rear Axle Ctr Joint
- Brad - Steering Column
- Brad Courtesy Lamp Switch
- Brace - Engine to Transmission
- Bracket A/C Comp Mounting
- Bracket A/C Condenser Mt
- Bracket A/C Hose
- Bracket Assembly
- Bracket Assembly - Front/Rear Seat Side Armrest Mounting
- Bracket Assembly - Rear Recovery
- Bracket Assembly - Rear Axle Damper
- Bracket for Radius Arm
- Bracket Radius Arm
- Bracket Stabilizer Bar Link
- Brake Adjuster Screw
- Brake Adjuster Spring
- Brake and Clutch
- Brake Block
- Brake Booster Control Seal
- Brake Caliper Support
- Brake Line - Metal
- Brake Master Cylinder
- Brake Master Cylinder Gasket
- Brake Master Cylinder Seal
- Brake Master Cylinder Switch
- Brake Pressure Accumulator
- Brake Pressure Sensor
- Brake Shoe Anchor Pin
- Brake Shoe Hold Cup
- Brake Shoe Hold Spring
- Brake Vacuum Booster Seal
- Brake Vacuum Booster
- Brush and Spring Alternator
- Bumper - Front Axle
- Bumper - Rear Axle
- Bushing - All Internal and External
- Bushing - Brake Pedal
- Bushing - Control Arm
- Bushing - Door Hinge
- Bushing - Front Lower Arm
- Bushing - Front Suspension
- Bushing - Front Suspension Upper
- Bushing - Front Suspension Upper Lever
- Bushing - Front Suspension Upper Lever Shaft
- Bushing - Front/Rear Axle Adjuster
- Bushing - Front/Rear Seat Track
- Bushing - Rear Lower Arm
- Bushing - Rear Suspension
- Bushing - Spindle
- Bushing Assembly - Rear Suspension
- Bushing Front Spring
- Bushing Lockout Hub
- Button - Parking Brake
- Button - Parking Brake Handle
- Cable - Front/Rear Seat
- Cable - Speed Sensor
- Adjuster Actuator
- Cable Assembly - Brake
- Cable Assembly
- Cable Assembly - Control Select
- Cable Assembly
- Cable Assembly - Speedometer
- Cable Front/Rear Seat
- Rear Adjuster
- Calipers (Brakes)
- Caliper Assembly - Front/Rear
- Camshaft and Lobes Assembly
- Camshaft and Lobes Assembly
- Camshaft Bearings
- Camshaft Sensor
- Camshaft and Pulley
- Cap - Brake Master Cylinder
- Cap - PTO Reservoir Filler
- Cap - Rear/Diff/Axle Control
- Cap - Shift Control
- Cap - Water Outlet
- Cap Assembly - Master Cylinder
- Cap Assembly - Radiator
- Cap Assembly - Reservoir
- Carrier - Brake Axle
- Carrier - Rear Axle
- Carrier Assembly - Differential
- Carrier Assembly - DD
- Case - Differential
- Case - A/C Evaporator
- Case Assembly - Differential
- Case Assembly - Power Divide
- Case, Differential Gear Support
- Catalyst Pellet/Monolith
- Heated/Separate Assembly
- Chain Timing
- Chain, Roller
- Child Seat Belt
- Cigar Lighter Assembly
- Cigar Lighter Connection Shell Liner
- Clip - Brake Shoe Leveler
- Clock Assembly
- Clutch and Pulley - Air Compressor
- Clutch Assembly - Direct One-Way
- Clutch Assembly - Planetary
- Clutch Bracket Assembly Fan
- Clutch Pack Assembly
- Resilient Displays
- Compass Assembly
- Compressor - Air Brake
- Compressor — Front Brake
- Cone and Roller - Drive Pinion Gear
- Cone Roller Front Wheel Outer
- Cone Roller Front Wheel Outer
- Connection - Water Outlet
- Control Arm Assembly - Front
- Control Arm Assembly - Rear
- Suspension Upper Lever
- Control Assembly - Shift Lock
- Control Assembly - Light Dimmer
- Control Assembly
- Control Assembly
- Control Assembly
- Valve Body
- Control Head - Rear
- Control Module - Air Suspension
- Control Module - Heated Windshield
- Control Unit - Anti-Lock
- Control Valve Seals
- Control, Valve Body
- Converter Assembly
- Converter Pressure Valve
- Coolant Hose
- Coolant Pump
- Coolant Temp Switch
- Coolant Tube Assembly - Inlet
- Coolant Tube Assembly - Outlet
- Cooler - Condenser Oil
- Cooler - ESR Oil
- Cooler - Transmission Oil
- Cooler Assembly
- Cooler Assembly - Power Steering Oil
- Cooler Assembly ESR Oil
- Cooler Assembly - Transmission Oil
- Cooler, Oil Housing
- Cooler, Cylinder Tubing Oem
- Cooler - Oil Level
- Cooler - Rear Axle Oil
- Cooler - Reverse Band Servo
- Cooler - Transmission
- Cooler, Cylinder Tubing Oem
- Cooler Assembly
- Cooler Assembly - Flywheel
- Cooler Assembly - Rear Engine
- Cooler Assembly - Valve Front Rail
- Cooler - Front/Rear Seat Track
- Cooler - Power Steering
- Cooler - Transmission Mounting
- Condenser Vent Tube
- Cooler, Condenser Oem
- Crankshaft Bearings
- Cup Wheel Bearing
- CV Joint Assembly - Inboard
- CV Joint Assembly - Outboard
- Cylinder - Door Lock
- Cylinder Assembly - Direct Injection
- Cylinder Assembly - Door Lock
- Cylinder Assembly - Power Steering
- Cylinder Assembly - Rear Brake
- Cylinder Block
- Cylinder Head
- Temperature Sensor
- Cylinder Keys Latch
- Cylinder Shaft Assembly - A/C Compressor
- Damper - Front Axle
- King Pin
- Damper - Crankshaft
- Damper - Door Arm
- Damper - Steering Wheel
- Damper Assembly - Timing Case
- Damper Drive Line Vibration
- Damper Front Spring
- Damper Rear Spring
- Damper Assembly - Control
- Dashpot Assembly - TV Cable
- Data Link Assembly
- Data Link Connector
- Deck Shield
- Deck Shield and Display
- Decelerator Cam Fuel Pump
- Diaphragm Assembly - TV Cable
- Diesel Fuel Injectors
- Diesel Injector Pump
- Differential Case
- Differential Assembly - Rear
- Differential Case Cover
- Support
- Differential Locking Assembly
- Differential Side Gears
- Differential Side Gears
- Dipstick Assembly
- Electric Power Steering
- Electric Power Steering Assist Assembly
- Electric Water Pump (Hybrid)
- Electronic Actuator Assembly
- Electronic Compass Assembly
- Electronic Control Assembly
- Electronic Pressure Control Solenoid
- Electronic Shift Control
- Electronic Speedometer
- Emissions Air Pump
- Engine Block
- Engine Control Module
- Engine Front Support Mount
- Engine Oil Pump
- Engine Torque Rod/Mount
- Equalizer - Parking Brake
- Exhaust Control Assembly
- Extension Housing
- Fan - Air Conditioner
- Fan - Air Conditioner
- Fan Assembly - Alternator
- Fan Assembly - Heater Hose
- Fan Assembly - Motor
- Fan Clutch Assembly
- Filler - Power Steering Pump
- Filler Housing
- Filler - Power Steering Column Tube
- Flange - Drive Shaft
- Flange - Universal Joint Axle
- Flange Universal Joint Spline
- Flapper Valve - Fuel Filler Pipe
- Fork - Gear Shifter
- Fuel Injection Assembly
- Fuel Injection Module
- Fuel Level Sensor
- Fuel Line - Metal
- Fuel Pump Assembly
- Fuel Pump Assembly
- Fuel Sep Fuel Vacuum
- Fuel Tank Vapor Valve
- Fuel Tank and Metal Lines
- Fuel Tank Assembly
- Fuel Vapor Canister
- Gasket - Camshaft Lid
- Gasket - Cylinder Head Cover
- Gasket - Engine Pan
- Gasket - Input Shaft Bearing
- Gasket - Locknut Hub
- Gasket - Master Cylinder
- Gasket
- Gasket - Oil Cooler
- Gasket - Oil Filter Adapter
- Gasket - Oil Pan
- Gasket - Power Steering Pump
- Gasket - Pump Cover
- Gasket - Pressure Regulator
- Gasket - PTO Cover
- Gasket - Rear Axle
- Gasket - Rear Window
- Gasket - Reverse Servo Piston
- Gasket - Trans. Assembly
- Gasket - Trans. Rear Shift
- Gasket - Transmission
- Gasket - Turbocharger
- Gasket - Turbo Oil Tube
- Gasket - Turbocharger
- Gasket - Valve Body
- Gasket - Wiring Connector
- Gasket and Shaft Seal
- Gauge Assembly Vacuum
- Gear - Camshaft Drive
- Gear - Crankshaft Drive
- Gear - Differential Drive
- Gear - Engine Balancer Shaft
- Gear - Low and Reverse
- Gear - Oil Pump Drive
- Gear - Output Shaft
- Gear - Reverse
- Gear - Reverse Idler
- Gear - Transmission
- Gear - Transmission Countershaft
- Gear - Transmission
- Gear Assembly - Intermediate
- Gear and Pinion
- Gear Assembly - Front Drive
- Gear Assembly - Intermediate
- Gear and Pinion - Power Steering
- Gear Assembly - Rear Axle
- Gear Assembly Spare Wheel
- Gear Assembly Steering
- Gear Assembly - Clutch
- Gear Assembly - Reverse Idler
- Gear Housing Column Lock
- Gear/Hub - Auxiliary Trans.
- Generic Electronic Module
- Governor Assembly
- Governor Weight
- Housing and Bearing
- Housing and Inner
- Housing and Inner Assembly Transaxle
- Housing Assembly
- Housing Assembly - Rear Axle
- Housing Assembly - Steering
- Housing Cover - Downshift
- Hub - Differential Gear Clutch
- Hub - Drive
- Hub - Intermediate Clutch
- Hub - Synchronizer
- Hub - Transmission Output Shaft
- Hydraulic Actuator Assembly
- Hydraulic Control Assembly
- Hydraulic Pump
- HVAC (High Intensity Discharge)
- Headlights - Factory-Installed
- High Voltage Charger
- Ignition Coil
- Ignition Coil Assembly
- Impeller
- Impeller Battery Pan
- Hybrid DC to DC Converter
- Hybrid Inverter
- Hybrid Transmission
- Hybrid Transmission Display
- Hybrid Traction Electric Motor
- Hydraulic Actuator Assembly
- Idler Assembly
- Idler Assembly - Timing Belt
- Ignition Cylinder Lock
- Impeller Water Pump
- Indicator - Rear Bracket
- Indicator Assembly - Manual
- Insulator - Engine Mount
- Insulator - Rear Axle
- Intake Manifold Gasket
- Intermediate Seal Rolls
- Intermediate Shaft
- Jack - Hydraulic Floor
- Jack - Screw
- Jack Assembly - Hydraulic
- Jack Handle
- Jack Screw
- Jack Screw Assembly
- Jackshaft Assembly
- Jackshaft Bearing
- Jackshaft Gear
- Jackshaft Shaft
- Jackshaft Thrust Washer
- Jackshaft Thrust Washer
- Jackshaft Thrust Washer