

Mopar Vehicle Plan Comparison





Maximum Care verses Added Care Plus, Added Care and Powertrain Care Plus

For New and Pre-Owned Vehicles













COMPARE COVERED COMPONENTS

	Basic Protection	Good Protection	Better Protection	Best Protection
	Powertrain Care Plus sM	Added Care sm	Added Care Plus [™]	Maximum Care ^{sм}
Engine	•	•	•	•
Transmission	•	•	•	•
Driveline	•	•	•	•
Steering	•	•	•	•
Air Conditioning	•	•	•	•
\$100 Towing Allowance	•	•	•	•
First Day Rental/Car Rental Allowance	•	•	•	•
Brakes		•	•	•
Power Group		•	•	•
Engine Cooling and Fuel		•	•	•
Front Suspension		•	•	•
Electrical		•	•	•
Rear Suspension			•	•
Luxury Group			•	•
Instrumentation			•	•
Anti-Lock Brakes			•	•
Expanded Electrical			•	•
Body Mechanisms				•
Manual Interior Mechanisms				•
Safety and Security				•
Full Mechanical				•

MAXIMUM CARESM

SERIOUS PROTECTION FOR YOUR VEHICLE

Maximum CareSM provides Full Mechanical Coverage for:



Engine



Transmission



Driveline



Steering



Air Conditioning



Engine Cooling and Fuel System



Electrical/Expanded Electrical



Front/Rear Suspension



Brakes/Anti-Lock Brakes



Instrumentation



Power Group



Luxury Group



Body Mechanisms



Manual Interior Mechanisms



Safety and Security

PLUS

- All Electrical Systems
- All Engine Computers
- Shocks
- Torsion Bars
- Engine Mounts
- All Seat, Hood, Trunk Lid, Liftgate, Door and Window Mechanisms, and much more!

WHAT'S NOT COVERED UNDER OUR MAXIMUM CARESM PLANS

The only parts and labor not covered:

- Maintenance services and items used in such services
- Wear items (such as tires, manual clutch) assembly, brake pads, shoes, rotors, drums, belts and wipers)
- Snow plows, winches and trailer hitches
- Body and paint items, including soft trim
- Glass and plastic lenses

MAXIMUM CARESM COMPONENT COVERAGE

IF IT'S MECHANICAL, IT'S COVERED.

GASOLINE ENGINE

- Cylinder Block and all Internal Parts
- Cylinder Head Assemblies
- Timing Case
- Timing Chain
- Timing Belt
- Gears and Sprockets
- Harmonic Balancer
- Oil Pump
- Water Pump and Housing
- Intake and Exhaust Manifolds
- Flywheel with Starter Ring Gear
- Core Plugs
- Valve Covers
- Oil Pan
- Oil Filter Adapter Housing
- Turbocharger Housing and Internal Parts
- Turbocharger Wastegate Actuator
- Supercharger
- Fuel Injectors (excluding clogged injectors)
- Serpentine Belt Tensioner

- Seals and Gaskets
- Variable Valve Timing Solenoids and Actuators

DIESEL ENGINE

- Cylinder Block and all Internal Parts
- Cylinder Header Assemblies
- Timing Gears and Cover
- Harmonic Balancer
- Oil Pump
- Water Pump and Housing
- Intake and Exhaust Manifolds
- Core Plugs
- Valve Covers
- Oil Pan
- Turbocharger Housing and Internal Parts
- Fuel Injection Pump and Injectors (excluding clogged injectors)
- Seals and Gaskets



- High-Pressure Oil Pump
- High-Pressure Oil Rails

TRANSMISSION

- Transmission Case and all Internal Parts
- Torque Converter
- Drive/Flex Plate
- Transmission Range Switch
- Transmission Control Module
- Bell Housing
- Oil Pan
- Gear Shifter and Shifter Mechanism
- Seals and Gaskets

Manual transmission clutch parts are not covered at any time.

FOUR-WHEEL DRIVE (4X4)

- Transfer Case and all Internal Parts
- Axle Housing and all Internal Parts
- Axle Shafts
- Axle Shaft Bearings
- Drive Shaft Assemblies (front and rear)
- Drive Shaft Center Bearings
- Universal Joints and Yokes
- Disconnect Housing Assembly
- Seals and Gaskets

MAXIMUM CARESM COMPONENT COVERAGE CONTINUED

ALL-WHEEL DRIVE (AWD)

- Power Transfer Unit and all Internal Parts
- Viscous Coupler
- Axle Housing and all Internal Parts
- Constant Velocity Joints and Boots
- Rear Driveline Module
- Drive Shaft and Axle Shaft Assemblies
- Differential Carrier Assembly and all Internal Parts
- Output Bearing
- Output Flange
- End Cover
- Overrunning Clutch
- Shift Motor
- Vacuum Motor
- Torque Tube
- Pinion Spacer and Shim
- Seals and Gaskets

FRONT-WHEEL DRIVE

- Transaxle Case and all Internal Parts
- Axle Shaft Assemblies
- Constant Velocity Joints and Boots
- Wheel Bearings

- Differential Cover
- Oil Pan
- Transaxle Speed Sensors
- Transaxle Solenoid Assembly
- PRNDL Position Switch
- Shifter Mechanism
- Transaxle Electronic Controller
- Torque Converter
- Seals and Gaskets

Manual transmission clutch parts are not covered at any time.

REAR-WHEEL DRIVE

- Rear Axle Housing and all Internal Parts
- Axle Shafts
- Axle Shaft Bearings
- Drive Shaft Assemblies
- Drive Shaft Center Bearings
- Drive Shart Center Bearings
- Universal Joints and Yokes
- Seals and Gaskets

STEERING

- Steering Gear Housing and all Internal Parts
- Power Steering Gear

- Power Steering Pump and Reservoir
- Steering Shafts (upper and lower)
- Steering Shaft Lower Coupling
- Rack and Pinion Assembly
- Rack and Pinion Boots
- Electronic Steering Motor
- Seals and Gaskets
- Inner Tie Rods
- Outer Tie Rods
- Drag Link
- Idler Arm
- Pitman Arm
- Steering Stabilizer
- Power Steering MotorsPower Steering Pump Cooler
- Telescoping Steering Column Motors

AIR CONDITIONING

Factory- or manufacturerauthorized air conditioning installations only.

- Air Conditioning Compressor
- Clutch
- Coil
- Condenser

- Front Evaporator
- Rear Evaporator
- Receiver-Drier
- Expansion Valve
- Hoses and Lines
- Low-Pressure Cut-Off Switch
- High-Pressure Cut-Off Switch
- Clutch Cycling Switch
- Front Instrument Panel Control Assembly
- Rear Instrument Panel Control Assembly
- Power Module
- Front and Rear Air Conditioning/ Heater Blower Motor
- Seals and Gaskets
- Blend Air Door Actuators and Motors
- Housing
- Blower Motor Resistor

ENGINE COOLING AND FUEL

- Cooling Fan
- Clutch and Motor
- Radiator
- Coolant Temperature Switch

- Fuel Pump
- Water Pump and Housing
- Fuel Tank Sending Unit
- Fuel Pressure Regulator
- Fuel Pressure Sensor
- Fuel Tank and Lines
- Serpentine Belt Tensioner
- Engine Oil Cooler
- Transmission Oil Cooler
- EGR Cooler
- Seals and Gaskets

FRONT SUSPENSION

- Shocks
- Struts
- Strut Mounting Plates
- Strut Mounts
- Bushing and Bearings
- Upper and Lower Control Arms
- Control Arm Bushings
- Thrust Arms
- Upper and Lower Ball Joints
- Wheel Bearings
- Air Suspension System
- Coil Springs
- Torsion Bars

REAR SUSPENSION

- Rear Leaf Springs
- Rear Coil Springs
- Auxiliary Springs
- Spring Interliner
- Spring Bushing
- Spring Shackle
- U-Bolt Rear Spring
- Spring Hanger
- Axle Trac Bar
- Lateral Link Arm
- Shocks
- Shock Mount Plate
- Struts
- Strut Mounting Plates
- Strut Bushings
- Rear Wheel Bearings
- Rear Trailing Arm Assembly
- Rear Stabilizer/Sway Bar
- Rear Stabilizer/Sway Bar Link
- Rear Stabilizer/Sway Bar Bushing
- Rear Wheel Bearings
- Rear Torsion Arms
- Rear Torsion Bars

BRAKES

- Master Cylinder
- Assist Booster
- Wheel Cylinders
- Disc Brake Calipers and Pistons
- Brake Lines
- Hoses
- Fittings
- Proportioning Valve
- Seals and Gaskets Brake shoes, pads, rotors

and drums are not covered at any time.

ANTI-LOCK BRAKES (ABS)

- Brake Systems Hydraulic Assembly
- Pump Motor Assembly
- Controller
- Sensors and Relays
- Seals and Gaskets

ELECTRICAL

- All wiring harnesses
- Starter Motor and Solenoid
- Generator (Alternator)
- Engine Control Module (Single

Module Engine Controller [SMEC])

- Powertrain Control Module
- Distributor
- Ignition Coil
- Coil Pack Assembly
- Voltage Regulator
- Horn and Horn Pad
- Transmission Control Module
- Electronic Fuel Injection System (excluding clogged injectors)
- Windshield Wiper Motor
- Rear Window Wiper Motor
- Wiper Control Module
- Manually Operated Electrical Switches
- Neutral Safety Switch
- Temperature Sending Unit/Switch
- Oil Level and Oil Pressure Sending Unit/Switch
- Body Computer
- Body Control Module
- Factory-installed Radio
- Speakers and Rear Entertainment Systems (includes CD and DVD players)

MAXIMUM CARESM COMPONENT COVERAGE CONTINUED

- Factory-installed U-Connect System
- Factory-installed Navigation Systems (excludes navigation disc)
- Audio Amplifier
- Gateway Module
- Ignition Module

Any remote transmitters and headphones are not covered at any time.

INSTRUMENTATION

- Electronic Instrument Cluster
- Amp/Voltmeter Gauge
- Fuel Gauge
- Temperature Gauge
- Tachometer
- Oil Pressure Gauge
- Turbo Gauge
- Speedometer

POWER GROUP

- Rear Window Defroster
- Power Window Motors
- Power Window Flex Track

- Power Antenna
- Power Seat Motors
- Power Door Locks and Linkage
- Power Sliding Rear Window Motor and Regulator (Trucks)
- Vacuum Pump
- Power Sliding Door Motor
- Power Liftgate

LUXURY GROUP

- Keyless Entry Sensors and Receiver/Module
- Trip Computer
- Message Center
- Overhead Electronic Vehicle Information Center
- Overhead Electronic Compass/Temperature
- Power Sunroof Motor
- Convertible Top Motor
- Electric Mirror Motor and Controls
- Cruise Control Servo
- Headlight Door Motor
- Concealed Headlamp Module
- Park Assist Module
- Park Assist Sensors

- Back-up Assist Camera
- Door Latches
- Heated Seat Systems
- Factory-installed Remote Start Systems (excluding transmitters)
- Heated Steering Wheel
- USB Outlets
- 120-Volt Outlets
- In-Vehicle Wireless
 Charging Station

 Remote transmitters are not covered at any time.

SAFETY SYSTEMS

- Air Bags (excluding deployed air bags)
- Impact Sensors
- Occupancy Sensors
- Seatbelt Retractors
- Seat Belt Buckles
- Modules
- Sensors and Switches

Note: Air Bags that have been deployed are not covered.

MOPAR ACCESSORIES

All electrical and mechanical Mopar accessories are covered provided they were installed by an authorized Chrysler Group facility.

- Audio Systems (including compact disc players)
- Sirius Satellite Radio
- Speed Control
- EVS (Security Systems)
- Clocks
- Remote Trunk Release
- Transmission Oil Cooler
- Remote Control Outside Mirrors
- Power Sliding Rear Window Assembly (Trucks)
- MoparConnect
- Rear Seat Video Entertainment Systems (including DVD players)
- Remote Start Systems (excluding transmitters)

FEATURES AND BENEFITS

FIRST DAY RENTAL

Provides a \$35 First Day Car Rental Allowance or Taxi Reimbursement for any dealership mechanical repair or maintenance service (excluding bodywork).

CAR RENTAL ALLOWANCE

Will pay up to \$35 per day (\$175 maximum per occurrence) for Car Rental or Taxi Reimbursement anytime a component covered by the plan or Basic Warranty fails, causing the vehicle to be inoperable and repairs take overnight.

\$100 TOWING ALLOWANCE

Will pay up to \$100 per occurrence for towing to the nearest Chrysler Group dealer anytime a component covered by the plan fails, requiring the vehicle to be towed.

PERSONALIZED PLAN PROVISIONS

Upon receipt and approval of a Mopar Vehicle Protection plan application form, you will be mailed personalized plan provisions. They will identify you and your vehicle to the servicing dealer as being eligible for plan service.

TRANSFER POLICY

A Mopar Vehicle Protection plan can make your vehicle more valuable and easier to sell. Remaining plan coverage may be transferred to the subsequent purchaser of the vehicle at the time of vehicle sale. A \$50 plan transfer fee will be applied (in most states).

Note: See your dealer for additional details, eligibility and restrictions.



